

Assembly Instructions for The Karma Coolac Salon Chair

Thank you for purchasing the Karma Coolac Salon Chair

First remove all items from the carton.

Open the smaller carton with the Hydraulic pump, handle and screws.

Secure the hydraulic pump to the base using the 4 screws supplied. The screws need to come through from the bottom of the base and into the bottom of the hydraulic.

Start all 4 screws first before fully tightening them with the provided allen key. It will be easier with 2 people and you can stand the hydraulic upside down and line the screw holes up.

Next fit the pump handle, the rubber end should be pointing down and the end where it connects to the hydraulic should be at a right angle. Secure the handle with the screw provided and place the plastic cap over the screw.

There will be a small slotted locking pin, this goes into the top of the hydraulic and is a locking pin. One end is tapered and it needs to be tapped in. This pin is not essential and assists with the chair locking into place from turning when lifting the handle up, this can be discarded if you are not fitting it.

Sit the top of chair on the hydraulic, if you have inserted the locking pin, line the pin up with the slot in the bracket.

Remove the 4 screws from the backrest, sit the back rest in place and start all 4 screws before tightening them all.

Now fit the foot rest if you are planning to use it by laying the chair in its side, remove the 3 screws from under the front of the chair in the middle, line up the top of the foot rest and put the screws back in, starting them all first before fully tightening them.

If you have any questions or require more information please contact your place of purchase.