

Assembly Instructions for Karma Driver Trolley

Thank you for purchasing the Karma Driver Trolley. Below are the step-by-step instructions for the assembly.

1. Carefully remove all items from the carton and stand the draw upright with the back of the draw on the floor and the draw facing up.
2. Connect the two frame pieces to either side of the trolley using the screws provided screwing them in most of the way but do not fully tighten them at this time.
3. Place the first shelf in place between the legs where the holes are in the frame at the bottom of the trolley (it's easier if you do the bottom shelf first). The centre of the hole should be in the centre of the shelf. Before screwing in, make sure the shelf is evenly spaced to the front and back of the frame. You may need to lift the frame slightly to even it out. There is no need to predrill the shelves.
4. Attach the upper shelf. There will be no need to worry about it being centred as the lower shelf is holding the frame in the correct position.
5. Attach the wheels by screwing them fully into the bottom of the frame.
6. Stand the trolley onto its wheels and fully tighten the screws on the side of the draws.
7. Open the draw, unscrew the handle, reverse the screws and reattach the handle.

The trolley is now ready to use.

Please contact your place of purchase if you are having any issues with your product.