

Assembly instructions for 0909**** Wellington Hydraulic Bed

There will be 2 boxes for this bed. The smaller box has the bed middle frame and the cover for the Hydraulic.

1. Remove all the parts and take off all the packaging.
2. Screw the adjustable legs into the bottom of the base.
3. Position the hydraulic into the base section making sure the poles for the stepper are facing the long ends of the base (these are 2 silver studs with holes in them). The stepper needs to be facing the side of the bed.
4. Connect the 4 nuts to the bolts on the bottom of the hydraulic, make sure you include the washers first then fully tighten.
5. Insert the stepper into the 2 chrome poles in the hydraulic and tighten the grub screws in the sides of the poles using an Allen key.
6. Next lay the cushion sections face down, remove the screws from the centre back cushion. Now place the top frame over the holes and put the bolts you removed back into the back. Start them all first before fully tightening. +
7. Attach the 2 chrome brackets into either end of the top frame section that hold the back and leg sections.
8. Have someone assist you and flip the top section onto the top of the hydraulic and secure with the nut in the top of the hydraulic (this may be inserted into the top of the hydraulic when received).
9. Now connect the springs from the chrome brackets to the small opening on the top frame section. Be careful not to over stretch the spring as it will not work as effectively as it should.

