

Tumut Assembly Instructions

What you need: Hammer and Drill with allen key attachment (these are not necessary just to help)

What's in the box:




Step 1: Remove everything from box. Please do not drag the parts across the ground.

Step 2: Flip the base and pump upside down, then place the base on top of the pump, should look like this Picture below. Then insert each screw (6) into the associated holes in the base, you can screw in with fingers and then tighten with provided allen key. Flip back over.



Note: Make sure you screw in from the bottom otherwise it won't fit and the screws will scratch. Matte finish scratches easily on the pump only.

Step 3: Insert pump lever into pump with the stand between the two rods, should look like this (picture). Insert until you can see the two holes in the rods come through.



Step 4: Assemble the chair top, remove the 4 bolts from the back of the backrest using the provided allen key, see before and after of chair back.



Step 5: Insert backrest against metal plate and lineup the metal plate holes with the backrest holes and insert screws.




Step 6: Hammer in locator pin into top of pump, only needs to go in halfway.

Note: This is not 100% necessary, just a bit of extra guidance for the connection of base to chair top.



Step 7: Attach footrest to base of chair top by removing the 4x screws from base, as pictured below. Line up footrest holes to the holes in the base of the chair top and screw in screws.




Note: May have to put tension on the sides of the footrest so the holes can align.



Should look like this.

Step 8: Place the chair top on top of the pump and align the locator pin (if used) with the divert in base plate, as pictured below.

Note: The pin won't align flush.



Step 9: Add weight to the chair to lock in pump and chair top.



Then your chair should look like this.

Dimensions:

Height:

Pumped up: base to ground 51cm, top of head rest to ground: 107cm

Pumped down: base to ground 38.5cm, top of head rest to ground: 95cm

Width:

Inner seat: 48cm, with armrests: 62cm

Seat depth: 47cm, 53cm (reclined)

Length:

Longest point (backrest laid down to end of footrest): 123cm

Backrest to end of footrest: 86cm