



USER MANUAL
Half-moon shaped wall lamp

Model Wall lamp



FC CE RoHS

Please read this manual carefully and use it correctly
and keep it properly.



COMMODITIES PARAMETERS
MADE IN CHINA

Input power	110-240V/50-60Hz
Output power	48W
Adjustment range	0%~100%
CCT (Correlated Colour Temperature)	2700K~5600K
CRI (Colour Rendering Index)	RA>90
Lumen	3360LM
Light Source	LED
Life span	50000h
Material	Aluminium,Metal,PVC

FUNCTION INTRODUCTION


Power Adjustment:

- Rotate the switch knob clockwise to turn on the power. The light intensity increases clockwise and decreases counterclockwise by 1% each time
- Turning off – rotate power switch counterclockwise all the way to the end and you will hear a slight click sound to indicate it is turned off completely

CCT (Correlated Colour Temperature Adjustment:

- The colour temperature can be adjusted from 2700K to 5600K (clockwise to counterclockwise)
- Colour temperature changes by increments of 100k


Power CCT
Switch Dimmer




TO USE THE LAMP

1. Install the lamp to the working desk and connect with the power supply
2. Revolve switch change the light color (2700k-5600k) .
3. Revolve the button will result in regulation of the lamp brightness (dimming function) or ON /OFF the lamp. Revolve button when you are satisfied with the lamp brightness.
4. Lamp memorizes the brightness setting and it is used next.


FUNCTION INTRODUCTION



ACCESSORIES



INSTALLATION STEPS



ATTENTION: ACCOMPANY THE WARRANTY CLAIM.

Thank you for purchasing LED lamp.
Please read the manual carefully before using the lamp.
Warranty for the lamp is 24 months.
It is designed to maximize the quality and comfort of your work.
The manufacturer shall not be liable for any trauma of injuries caused to persons or damage to property caused by failing to follow instructions in this manual.

1. Clean with wet cloth or dry cloth only. Do not use aggressive cleaners to clean the lamp. The warranty period starts at the time of the use.
 2. Connect only with suitable power outlet 100-240V 50-60Hz. Do product original purchase. A Proof-of-Date not clean under running water. Document is a receipt/invoice of purchase.
 3. Keep out of reach of children the following conditions: The warranty of the lamp is not covered under.
 4. Keep away from water and fire -Normal wear and tear.
 5. Do not use the lamp if it has been damaged - Damage caused by transport or storage (dropped, exposed to water, fire or cable is -Damage caused by improper use. damaged)
 6. Do not touch the lamp with wet hands. manual. -Damage caused by non-compliance with this damage caused by alterations to the lamp.
- Disposal - Damage with a sharp object, the lamp being Do not dispose electrical appliances in household dropped. compression, falling into water or fire waste containers! In accordance with the directive Unauthorized repairs will void the warranty. Disposed in a non polluting way. Bring old If you do not have a receipt for purchase of this electrical appliances for recycling to the product. appropriate waste collecting stations.